

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39464**

2009-07 Jeep Wrangle (JK) (2 Door) 3.8L

w/ Rock Crawler Type-Off-Road Suspension System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. exhaust from behind the catalytic converters.

Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.

2. Install a 2 1/2" band clamp on the inlet of **52366**. Install front intermediate pipe **52366** onto the outlet of the converter pipe. Insert the rod hanger into the rubber isolator.

3. Install muffler **17263**. Slightly tighten the 2 1/2" clamp that connects this muffler to the outlet of the 53266 front pipe.

KIT CONTAINS:

- (1) 17263 MUFFLER
- (1) 52366 FRONT PIPE
- (1) 55428 TAIL PIPE
- (1) 36443 TIP
- (4) 2 1/2" BAND CLAMPS
- (1) 709043 INSTRUCTION SHEET

7. Please see the system diagram on the back page of these instructions.

6. Beginning at the inlet end, align the system components and fully tighten all the clamps.

5. Install the DynoMax tip **36443** on the outlet of the tail pipe using a 2 1/2" clamp.

4. Install tail pipe **55428**. Be sure to insert the metal rod hangers into the rubber isolators. Slightly tighten the 2 1/2" clamp that connects the tail pipe to the muffler outlet.

39464 SYSTEM DIAGRAM

