

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19419**

2005-06 Dodge Charger, Magnum, 3.5L /
Chrysler 300 3.5L Single Exhaust



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the old exhaust system from the vehicle. Use WD-40, or a similar lubricant, to aid in removing the rod hangers from the rubber isolators.
2. Install DynoMax front intermediate pipe **54355**. Finger tighten the front 2¼" clamps.
3. Install DynoMax Super Turbo muffler **17662**. Finger tighten the 2½" clamp on the connection to 54355.

4. Install tail pipe **55232**. Insert the rod hangers (3) into the rubber isolators on the chassis. Finger tighten the 2½" clamp that connects to muffler 17662.
5. Beginning at the inlet end, align all components and tighten all the clamps. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 17662 MUFFLER
- (1) 54355 PIPE
- (1) 55232 TAIL PIPE
- (2) 2¼" CLAMPS
- (2) 2½" CLAMPS
- (1) 701463 INSTRUCTION SHEET

19419 SYSTEM DIAGRAM

