

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19427**

2005-06 Chevrolet Silverado 1500 / GMC Sierra 1500
5.3L Crew Cab, Short Bed, 2WD/4 WD



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar lubricant, to aid in removal of the metal rod hangers.
2. Install DynoMax inlet pipe **55280**. Insert the metal rod hanger into the rubber isolator on the chassis. Finger tighten the nuts on the inlet flange.
3. Install DynoMax Super Turbo muffler **17673**. **The installation direction is stamped on the cover of the muffler.** Finger tighten the 3" inlet clamp.
4. Install DynoMax tail pipe **55513** with **36474** stainless steel tip. Insert the metal rod hangers into the two rubber isolators on the chassis. Finger tighten the 3" clamp.
(NOTE: The tail pipe comes with two rear rod hangers on the pipe. Use the hanger that aligns with the rubber isolator location on your truck.)

5. Beginning at the inlet end, align the system and fully tighten all the clamps.
6. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 17673 MUFFLER
- (1) 55280 INLET PIPE
- (1) 55513 TAIL PIPE
- (1) 36474 TIP w/BAND CLAMP
- (2) 3" CLAMPS
- (1) 702104 INSTRUCTION SHEET

19427 SYSTEM DIAGRAM

