

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39501**

2010-09 Chevrolet Colorado / GMC Canyon 5.3L



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe assembly from vehicle. Lubricate the rubber isolators with WD-40, or similar lubricant, to aid in removing the metal rod hangers from the the rubber isolators.
2. Install DynoMax front pipes **52475** and **53751**. Insert the metal rod hangers into the rubber isolators on the chassis. Slightly tighten the clamp and flange nuts on the exhaust pipes.
3. Install DynoMax Ultra Flo Welded muffler **17221**. The muffler should lie flat and install with the center connection as the inlet with the side outlet connection toward the driver side. Slightly tighten the 3" inlet clamp at the connection to the front pipe.
4. Install DynoMax tail pipe **55562**. Insert the two (2) metal rod hangers into the rubber isolators on the chassis. Slightly tighten the 3" clamp to the muffler outlet.

5. Install the **36505** tip with the supplied band clamp or use optional **42448** spout with clamp **35978**.
6. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps.
7. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17221 MUFFLER
- (1) 52475 INLET PIPE
- (1) 53751 Y-PIPE PIPE
- (1) 55562 TAIL PIPE
- (1) 36505 TIP
- (1) 42448 SPOUT
- (1) 35978 CLAMP
- (1) 2½" BAND CLAMP
- (1) 2¾" BAND CLAMP
- (3) 3" BAND CLAMPS
- (1) 710846 INSTRUCTION SHEET

39501 SYSTEM DIAGRAM

