

INSTALLATION INSTRUCTIONS FOR

DynoMax System: 39535

**2015-12 Jeep Wrangler Unlimited w/3.6L
Cat-back single exhaust system.**



2701 N. Dettman Rd.
Jackson, MI 49201

NOTE: This exhaust system may not be compatible with aftermarket evaporative canister protection skid plates. Check the exhaust routing before trying to install.

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT LIGHT DUTY TRUCK BUMPER JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS, IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT, IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before beginning the installation.

1. Remove the O.E. exhaust from behind the catalytic converters. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install intermediate pipe **52561**. Insert the rod hanger into the rubber isolator. Slightly tighten the 2½" clamp on the inlet end. Please see the system diagram.
3. Install muffler **17283**. Slightly tighten the 2½" clamp that connects this muffler to the outlet of the 52561 front pipe.
4. Install connector pipe **51113**. Slightly tighten the 2½" clamp that connects the connector pipe to the muffler outlet.

5. Install the DynoMax resonator **24246**.
6. Install tail pipe **55428**. Insert the rod hangers into the rubber isolator.
7. Install tip **36484**.
8. Beginning at the inlet end, align the system components and fully tighten all the clamps.

KIT CONTAINS:

- (1) 52561 Intermediate Pipe
- (1) 17283 Ultra Flo Welded Muffler
- (1) 51113 Connector Pipe
- (1) 24246 Resonator
- (1) 55428 Tail Pipe
- (1) 36484 Tip w/Clamp
- (5) 2½" Band Clamp

39535 SYSTEM DIAGRAM

