

INSTALLATION INSTRUCTIONS FOR DYNOMAX DUAL KIT: 39310

2007-99 Chevrolet Silverado / GMC Sierra, 1500/2500
(<8600 G.V.W.R.) 4.3L, 4.8L, 5.3L Ext. Cab, Short Bed
(143.5" W.B., 2007 Classic Models ONLY)



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe assembly Use WD-40, or a similar product, to lubricate and help remove the metal rod hangers from the rubber isolator.
2. Install DynoMax front pipe **55512** to the outlet of the O.E. catalytic converter. Insert the rod hanger into the rubber isolator on the passenger side frame. Finger tighten the inlet flange fasteners.
3. Install DynoMax muffler **17228**. The muffler should lay flat when properly positioned. Slightly tighten 3" muffler inlet clamp.
4. Install hanger / clamp **36154**. Insert the rod into the rubber isolator on the chassis hanger.
5. To install tail pipe hangers **35103**, locate a hole in the frame about 7" forward of the leaf spring frame mount. This should be the same on both sides of the truck.

IMPORTANT: Move any wiring inside the frame away from the bracket so the wires do not get pinched or cut. Use the cable ties provided.

6. Install RH tail pipe **54674** and LH tail pipe **55514**.
7. Slip on tail pipe extensions **52440** on each side. Connect the 35108 hangers to the RH and LH pipes using the u-bolt clamps
8. Install the SS tips **36484** using the band clamps provided. See the system diagram
9. Beginning at the inlet end, position all components and tighten the clamps. Please see the full system diagram on the back page.

KIT CONTAINS:

- (1) 17228 MUFFLER
- (1) 55512 PIPE
- (1) 54674 PIPE
- (1) 55514 PIPE
- (2) 52440 PIPES
- (2) 36484 SS TIPS
- (1) 36363 BOLT KIT
- (1) 36154 CLAMP / HANGER
- (2) 35103 HANGERS
- (6) 2 1/2" BAND CLAMPS
- (2) 2 1/2" U-BOLT CLAMPS
- (1) 3" BAND CLAMP
- (2) CABLE TIES
- (1) 709328 INSTRUCTION SHEET

39310 SYSTEM DIAGRAM

