

2701 N. Dettman Rd. Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS OR SCISSOR JACK ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

- 1. Remove the O.E. inlet pipe/muffler/tail pipe welded assembly from the vehicle. Lubricate the rubber isolators with WD-40, or similar product, to aid in removal of the muffler metal rod hangers.
- 2. Install DynoMax Y-pipe **54739**. Reuse the O.E. band clamp on the front RH exhaust leg.
- 3. Depending on the wheelbase length of your truck, use the appropriate extension pipe as indicated: Please see system diagram.
 - a. Reg cab, 8' bed 137" WB no pipe required.
 - b. Super cab, 6³/₄' bed 141.8" WB use **51073** ext. pipe.
 - c. Crew cab, 6³/₄ bed 156.2" WB use **52481** ext. pipe.
 - d. Crew cab, 8' bed 158" WB use 52481 ext. pipe.
 - e. Crew cab, 8' bed 172.4" WB use **52481** and **52482** ext. pipes.
- 4. Slip clamp-on rod hanger **36409** over the inlet end and install DynoMax Ultra Flo Welded muffler **17557**. Do not tighten the band clamp at this time.

- 5. Slip a band clamp over the inlet end and install DynoMax tail pipe **55569**. Insert the metal rod hangers into the three (3) rubber isolators on the chassis and frame.
- 6. Install DynoMax SS tip **36477** using the supplied band clamp.
- 7. Beginning at the inlet end, align system and tighten all the clamps.
- 8. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

(1) 17557 MUFFLER
(1) 54739 Y-PIPE
(1) 51073 EXT. PIPE
(1) 52482 EXT. PIPE
(1) 52481 EXT. PIPE
(1) 55569 TAIL PIPE
(1) 36477 SS TIP
(1) 36409 CLAMP-ON ROD HANGER
(4) 4" BAND CLAMP
(1) 711098 INSTRUCTION SHEET

