

INSTALLATION INSTRUCTIONS FOR

DynoMax System: 39534

2016-15 Ford Mustang GT



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN BUMPER JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS, IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT, IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Please read all instructions before beginning the installation.

1. Remove the original exhaust system assembly from the vehicle. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front exhaust x-pipe **56260**. Slightly tighten the inlet 2¼" clamps.
3. Install DynoMax Ultra Flo Welded mufflers **53925** right hand and **53924** left hand. Slightly tighten the 3" clamps that connect the mufflers to the x-pipe.
4. Install DynoMax tips **36505** right hand and left hand.

5. Beginning at the inlet end, align all the parts and fully tighten all the clamps.
6. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 56260 Front X-Pipe
- (1) 53925 Muffler
- (1) 53924 Muffler
- (2) 36505 tip w/ Clamp
- (2) 36437 2¼" Band Clamp
- (2) 36439 3" Band Clamp
- (1) Instruction Sheet

39534 SYSTEM DIAGRAM

