

INSTALLATION INSTRUCTIONS FOR

DynoMax Super Turbo Axle-Back Kit: **39536**

2019-2018 Jeep Wrangler JL,
Wrangler Unlimited JL 2.0L Turbo, 3.6L V6



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN BUMPER JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS, IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT, IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. muffler assembly from behind the OE intermediate pipe. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install Dynomax Super Turbo SS muffler assembly **53992**. Slightly tighten the 2 ½" clamp that connects this muffler to the outlet of the OE intermediate pipe. Insert both rod hangers.
3. Install Dynomax SS tips **36472**. See the system diagram on the back page of these instructions.
4. Beginning at the inlet end, align the muffler assembly and fully tighten all the clamps.

KIT CONTAINS:

- (1) 53992 muffler
- (2) 36472 tip w/clamp
- (1) 36438 band clamp
- (1) Dynomax sticker
- (1) Instruction sheet

39536 SYSTEM DIAGRAM

